


Wheel and Belt Measuring Aids



INSTRUCTIONS ON HOW TO MEASURE BELT I N S I D E CIRCUMFERENCE

Take two (2) pencils and stretch to eliminate any slake. **DO NOT OVER-STRETCH.** Worn belts require a replacement of approximately 3% to 5% **SMALLER** size.

