

TELEVISION BRANDS / FULL NUMBER

	1408-179		1408-136
	1408-191		1408-139
	1408-199		1408-175
	1418-1		1408-180
	1418-2		1408-200
	7030		1418-4
	7031		1418-10
	7032		1418-12
P <u>PHILCO</u>		S <u>SEARS</u>	
	1408-105		1408-184
	1408-107		1418-4
	1408-110		1418-13
	1408-111	S <u>SHARP</u>	
	1408-112		1408-100
	1408-114		1408-103
	1408-116		1408-140
	1408-191		1408-141
	1418-1		1408-142
P <u>PHILIPS</u>			1408-143
	1408-161		1408-144
	1408-191		1408-167
Q <u>QUASAR</u>			1408-188
	1408-107		1418-6
	1408-111	S <u>SONY</u>	
	1408-112		1408-108
	1408-114		1408-109
	1408-191		1408-166
	1418-1		1408-169
R <u>CA</u>		S <u>SYLVANIA</u>	
	1408-102		1408-105
	1408-105		1408-107
	1408-107		1408-110
	1408-110		1408-111
	1408-111		1408-112
	1408-112		1408-114
	1408-114		1408-116
	1408-115		1408-191
	1408-116		1418-1
	1408-120		7030
	1408-131		7031
	1408-132		7032
	1408-155	T <u>TOSHIBA</u>	
	1408-183		1408-172
	1408-184		1408-181
	1408-185		1418-9
	1408-186		1418-10
	1418-1	Z <u>ZENITH</u>	
	1418-13		1408-109
	7030		1408-166
	7031		1408-169
	7032		1408-182
	7035		1408-194
S <u>AMSUNG</u>			1408-195
	1408-170		1418-3
	1408-171		1418-7
	1408-186		1418-12
	1408-187		
S <u>ANYO</u>			
	1408-113		
	1408-117		
	1408-121		
	1408-122		
	1408-127		
	1408-131		
	1408-132		
	1408-133		
	1408-134		
	1408-135		